



Bulwark® EXCEL FR® Classic Coverall. CEC2

PRODUCT MEASUREMENTS

	C38	C40	C42	C44	C46	C48	C50	C52	C54	C56	C58	C60	C62	C64
Chest	47 3/8	49 3/8	51 3/8	53 3/8	55 3/8	57 3/8	59 3/8	61 3/8	63 3/8	65 3/8	67 3/8	69 3/8	71 3/8	73 3/8
Waist	38 1/2	40 1/2	42 1/2	44 1/2	46 1/2	48 1/2	50 1/2	52 1/2	54 1/2	56 1/2	58 1/2	60 1/2	62 1/2	64 1/2
Sleeve Length from Center Back	32 1/2	33	33 1/2	34	34 1/2	35	35 1/2	36	36 1/2	37	37 1/2	38	38 1/2	39
Inseam	30 1/2	30 1/2	30 1/2	30 1/2	30 1/2	30 1/2	30 1/2	30 1/2	30 1/2	30 1/2	30 1/2	30 1/2	30 1/2	30 1/2

CHEST

Measured across the chest one inch below armhole when laid flat.

SLEEVE LENGTH FROM CENTER BACK

Measure From CB Neck to Shoulder Point to Finished Sleeve Hem.

INSEAM

Measured from crotch seam to hem.