# EDDIE BAUER



## Packable Wind Jacket. EB500

Wind w as the inspiration for this compact layer. Plus, it packs dow n into its ow n logoed pocket, making it easy to carry w herever you go. Hood w ith locking draw cords for adjustability, contrast reverse coil zipper, underarm vents, packable zippered chest pocket, front unzippered pockets, elastic cuffs and an open hem. Contrast Eddie Bauer logo on right chest. Made of 100% nylon.

CARE INSTRUCTIONS


Secure all garment before laundering Machine w ash w arm delicate separately Use mild detergent rinse thruoghly Do not bleach Tumble dry low or for best result line dry Do not iron. Do not dry clean





back

#### HOW TO MEASURE



#### CHEST WIDTH

Measure under the arm and around the fullest part of the chest with arms dow n, keeping tape horizontal.

### SIZE CHART

	XS	S	М	L	XL	2XL	3XL	4XL
Chest	32-34	35-37	38-40	41-43	44-46	48-50	52-54	55-57

#### COLOR INFORMATION

Please note: PMS code information is shown only when an exact match is available.





PMS BLACK C

